



WWW.SMITTYBILT.COM

Installation Instructions

Grille Saver License Plate
Relocation Bracket
Part # 4433

Note: Read instructions entirely before installing this accessory.

Parts Included	Qty	Tools Required
Bracket	1	Allen Wrench
Foam Pads	2	#2 Phillips Screwdriver
6 mm x 20mm Screw	2	

Step 1: Remove center screw from the bottom of the center tube on the back of the Grille Saver. (Fig 1)

Step 2: Loosely attach bracket on grille saver; note where the bracket comes into contact with the Grille Saver.


Step 3: Remove bracket and adhere foam padding to noted area from Step 2 on bracket. This will help protect the grille saver and reduce vibration. (Fig B,C)



(Fig A)



(Fig B)



(Fig C)

Step 4: Reinstall bracket on Grille Saver and secure completely. (Fig D, E)

Step 5: Install Grille Saver on vehicle per manufacturers' instructions.

Step 6: Determine the best mounting holes to use to attach your license plate. Attach license plate to bracket using the included hardware. (Fig F)

For Technical Support/Warranty Information please call 310-762-9944

Smittybilt, 400 West Artesia Blvd, Compton, CA 90220



WWW.SMITYBILT.COM

Installation Instructions

Grille Saver License Plate


Relocation Bracket

Part # 4433




Backside View

(Fig D)



(Fig E)




Determine the best mounting holes to use to attach your license plate. Attach license plate to bracket using the included hardware.

(Fig F)

Step 7: Installation is now complete.

Note: This bracket fits all Smittybilt Grille Savers and most after market Bull bars



Limited Warranties

Smittybilt's products are covered under the following limited warranties only. Note that the duration of the limited warranty differs according to the material and finish of the product purchased. Subject to the duration and conditions of the limited warranty stated below, Smittybilt warrants to the original retail purchaser that its products are free from defects in material and workmanship. All other warranties and representations express or implied, are hereby disclaimed, including fitness for merchantability and buyer's intended use or purpose. All parts are sold "AS IS" except for the limited warranties granted herein. Buyer assumes all risks as to the selection, suitability and performance of all goods and products selected. This limited warranty does not cover damage or impairment in any part due to misuse, improper installation, accident or contact with on-road or off-road hazards, product modification, improper or inadequate cleaning and/or maintenance. Smittybilt is not responsible for items damaged during shipping. This warranty is not transferable from the original buyer. For the original Buyer to be eligible for the limited warranty coverage, the Buyer must provide proof of purchase.

Customer's remedy hereunder shall be limited only to repair or replacement (at Smittybilt's option) of any defective part(s) returned to Smittybilt at customer's expense. The determination of whether or not a returned part is defective or subject to coverage under the limited warranties stated herein shall be made at Smittybilt's sole discretion.

To assure product quality, Smittybilt reserves the right to change product design, material, specification and finishes without prior notice to customers. This limited warranty gives you specific legal rights and you may also have other rights, which may vary from state to state. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply as to you. Also, some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. Smittybilt reserves the right to discontinue product lines and substitute products, or provide other remedies than those listed in this limited warranty for those discontinued products.

For Technical Support/Warranty Information please call 310-762-9944

Smittybilt, 400 West Artesia Blvd, Compton, CA 90220