



400 W. Artesia Blvd.,
Compton, CA 90220

SMITTYBILT TECHNICAL UPDATE

DATE 5-13-16

APPLICATION 97-2016 Wrangler

PART NO. 76856&76622& 76654

TECHNICAL ISSUE

Tire swing equipped with billet handle opens while driving.

CORRECTIVE ACTION

Order part#**76856-05**. Revised billet handle features locking pin to prevent handle from rotating from the locked position.

JK's only : Make sure latch support bracket (#76856-06) is installed on tire swing.

EXPECTED CORRECTION TIME

Corrected. See Corrective Action (above)

14 Days 30 Days 60 Days 90 Days

REQUIRES PART NOTE IN ISIS

YES NO

NOTES:

CONTACT TECH SUPPORT
FOR FURTHER QUESTIONS:
tech@smittybilt.com (800) 776-0767



400 W. Artesia Blvd.,
Compton, CA 90220

Revised 76856-05 billet handle features locking pin to prevent unwanted handle movement.

NOTE: Periodically lube pull pin and handle shaft with Break-Free CLP



76856-06 Latch
support bracket



76856-06 Latch support bracket install.



76856-05 install

Step 1: Remove current handle assembly and lock out bracket (if equipped) by removing the 2, 8mm bolts that hold it on. (Fig A, B)

Step 2: Insert new assembly into tire carrier and secure with previously removed bolts.



(Fig A)



(Fig B)

OPERATION

Step 1: Holding ring, lift up locking pin, then you can rotate your handle. You need to lift locking pin when your opening or closing you handle. (Fig C, D)



(Fig C)



(Fig D)



(Fig E)



(Fig F)

- Never rotate handle when pin is down (Fig E) Make sure pin/handle is locked when driving.
- Routinely lube locking pin (Fig F) (Break-free CLP or something similar)